

FRONT VIEW



Trademark of the DVB - Digital Video Broadcasting Project



- | | | |
|---|--------------------------------|---------------------------------|
| 1 TFT screen | 6 Joystick | 11 Reset (press 6s and release) |
| 2 Measurement key | 7 Installations management key | |
| 3 Spectrum key | 8 Settings key | |
| 4 TV Key | 9 Battery charging indicator | |
| 5 Export (press>1s)
Reference (press<1s) | 10 Softkeys | |

SCREEN ICONS REFERENCE

STATUS BAR

- Battery charging**
- Battery not charging.** Yellow level indicates charge left
- USB in serial port mode**
- Satellite band**
- Current voltage, 22 kHz signal and LNB power level**
- Terrestrial band**
- USB flash drive inserted**
- Current installation**
- Compressed installation**
- SatCR (SCD/EN50494) commands enabled**
- JESS (SCD2/EN50607) commands enabled**
- Task scheduled**
- Joystick multi-function enabled**
Two-letter code indicates the exact function:
 - FR** Frequency tuning
 - CH** Channel tuning
 - SP** SPAN change
 - MK** Marker moving
 - EC** Echo change/zoom

SERVICE LIST SELECTOR


- Digital TV service**
- High Definition TV service**
- Digital radio**
- Data**
- Scrambled service**

DIALOG BOXES

- Error message**
- OK message**
- Question message**
- Warning message**


VIDEO & AUDIO SETTINGS MENU

- TFT backlight brightness**
- Volume**






MEASUREMENT




FULL MEASUREMENT

1/3



MEASUREMENT + TV + SPECTRUM

2/3




MEASUREMENT + PARAMETERS

3/3




SPECTRUM ANALYSER




SPECTRUM + MEASUREMENT

1/3



SPECTRUM + MEASUREMENT + TV

2/3





FULL SPECTRUM

3/3




TV MODE




FULL TV

1/3



TV + SPECTRUM + MEASUREMENT


2/3




TV + SERVICE DATA

3/3

JOYSTICK




EXPORT*




*Export settings in Preferences


INSTALLATIONS MANAGEMENT



SPECTRUM ANALYSER MENU



TV MENU





UP



DOWN



LEFT



RIGHT



VALIDATE

PARAMETER EDITION



Tuning	
Channel:	44
Channel Plan	CCIR ▶
Tune By:	Channel ▶
Center Freq:	658.00 MHz ●



x3

Tuning	
Channel:	44
Channel Plan	CCIR ▶
Tune By:	Channel ▶
Center Freq:	658.00 MHz ●




Tuning	
Channel:	44
Channel Plan	CCIR ▶
Tune By:	Channel ▶
Center Freq:	658.00 MHz ●



Tuning	
Channel:	44
Channel Plan	CCIR ▶
Tune By:	Channel ▶
Center Freq:	658.00 MHz ●



Tuning	
Channel:	44
Channel Plan	CCIR ▶
Tune By:	Channel ▶
Center Freq:	658.10 MHz ●



Tuning	
Channel:	44
Channel Plan	CCIR ▶
Tune By:	Channel ▶
Center Freq:	658.10 MHz ●

PARAMETER SELECTION



Advanced	
Average	0 ●
Spectrum Line	Outline ◄



Advanced	
Average	0 ●
Spectrum Line	Outline ◄



Advanced	
Average	0 ●
Spectrum Line	Outline ◄

- Outline
- Solid
- Trans.




Advanced	
Average	0 ●
Spectrum Line	Outline ◄

- Outline
- Solid
- Trans.




Advanced	
Average	0 ●
Spectrum Line	Solid ◄




INSTALLATIONS MANAGEMENT






PREFERENCES MENU




SETTINGS MENU



MEASUREMENT MENU




TOP VIEW



12 RF input connector

SIDE VIEW

- 13 Power input connector
- 14 ON/OFF button
- 15 Video/Audio input
- 16 Mini-USB connector



RESET

If the device crashes, press the ON/OFF button (14) for 10 seconds. If the device does not respond then press the F4 key (11) for 6 seconds and then release to reset (see user's manual for more information).

